## **VPS Laser Device** VPSL-0685-050-X-5-A/B

- c. Soldering irons should be grounded to protect laser diodes from voltage leaks.d. During operation of the VPSL diode, working clothes, hats, and shoes should be static-



BSR165 12/29/2014